





Reparatur-Anleitung
Repair instruction

BLANCO CORESSA-F HD Hebel rechts BLANCO CORESSA-F HD Hebel links




BLANCO

BLANCO CORESSA-F







2,5 mm
Art.-No. 139 188







21 mm







 21 mm









 2,5 mm
Art.-No. 139 188



BLANCO

BLANCO CORESSA-F



BLANCO

BLANCO CORESSA-F

